




## Getting Started

Your new One For All remote offers you two quick and easy ways to set up:



### On-Remote Setup

You can follow the simple 1-2-3 setup steps on the remote itself. The instructions on this side of the Getting Started Guide show you how.




### Online Setup: SimpleSet.com

If you prefer, you can connect the remote to your PC or Mac, go to SimpleSet.com, and follow the online directions and videos. The other side of this Getting Started Guide has directions to get started with the online setup.

### What's in this package?

1 USB Cable



1 Remote


1 Getting Started Guide

For the complete user guide, troubleshooting tips, and customer support, visit [www.SimpleSet.com](http://www.SimpleSet.com) or call toll-free 1-800-315-0990



## On-Remote Setup

### 1 Install batteries in the remote.



Press the arrow on the battery door (on the back of the remote) to open it. Then install 2 AAA batteries (not included).

Put the battery door back in place and press until it clicks into place.

### 2 Find the brand of each device.

For each of your devices, circle your brand in the table below. (For example, if you have a Samsung TV, circle "Samsung" in the TV section.)

TV TV, HDTV, LCD, Plasma TV, Projector			
1 Insignia	6 Sanyo		
2 LG	7 Sharp		
3 Panasonic	8 Sony		
4 Philips, Magnavox	9 Toshiba		
5 Samsung	0 Vizio		

STB Satellite Receiver, Cable Box, Streaming Player, Other Video Accessory			
1 AT&T	6 Dish Network		
2 Cisco, Scientific Atlanta	7 Motorola		
3 Comcast	8 Pace		
4 Cox	9 Time Warner		
5 DirecTV	0 Verizon		

DVD DVD Player, Blu-ray, DVR, VCR			
1 Insignia	6 Samsung		
2 LG	7 Sharp		
3 Panasonic	8 Sony		
4 Philips, Magnavox	9 Toshiba		
5 RCA	0 Vizio		

### 3 Press and hold SETUP.



Press and hold the **SETUP** key until the **TV** key blinks twice.


**Note:** Make sure your device is on before you start. If you're programming a DVD player, media device, or anything else that plays back sound or video, make sure you have something playing.

### 4 Press the device key.




Press the key for the device you want to operate. For example, if you want to program the remote to operate your TV, press **TV**.

### 5 Point the remote at your device.



Keep the remote pointed directly at the front panel of the device you want to operate.

### 6 Press and hold the number key.



Press and hold the number for your brand that you circled for this device.

Keep holding the number key until your device turns off. Then release the number key.

**Note:** If the original remote for this device doesn't have a power key, the One For All remote will send a pause command instead.

### 7 Test the remote with your device.

**If you're satisfied with the way the remote operates it:** Follow the On-Remote Setup steps to program the remote for your next device.

**If the remote isn't operating your device like you think it should:** Try the on-remote setup for it again and keep holding the number key in step 6 until your device turns back on.

**Notes:** If you can't find a code that operates your device using the on-remote setup, use the USB cable that came with this remote to connect it to your PC or Mac and set up your remote online at SimpleSet.com (the other side of this sheet has directions).

You can also use one of the other programming methods, described in the owners manual available at SimpleSet.com.

## One For All SmartControl

One For All SmartControl lets you control up to 3 devices in your home theater without having to select the device keys—the volume, channel, and other keys automatically go to the right device!

Before you use One For All SmartControl for the first time, however, you need to set it up. Take a look at the devices you use when you watch TV or listen to music. Then choose that option in step 3 below.

### To set up One For All SmartControl:

- Press and hold **SETUP**. The **TV** key blinks twice.
- Press the SmartControl key you want to set up: for Watching TV and for Watching Movies. The TV key blinks twice.
- Press the number key from the table below that corresponds to the devices you use for this activity.

	WATCH TV	WATCH MOVIES
1	TV + Satellite Receiver/Cable Box/Streaming Player	TV + DVD player
2	TV + DVD player	TV + Satellite Receiver/Cable Box/Streaming Player
3	TV only	TV only

That's it! You've finished setting up One For All SmartControl.

### To use One For All SmartControl:

- Press the SmartControl key for the activity you want, for Watching TV or for watching Movies.
- Hold the key down until all of the devices for this activity turn on.


Now, your volume, channel, and playback control keys will automatically go to the right device for your home theater setup.

**Questions? Just call 1-800-315-0990.**



## Online Setup: SimpleSet.com


### 1 Install batteries in the remote.



Press the arrow on the battery door (on the back of the remote) to open it. Then install 2 AAA batteries (not included).

Leave the battery door off the remote for now—you're going to access the USB port below the batteries in the next steps.


### 2 Gather info on your devices.



Find the brand of each of your home theater devices and what kind of device it is (for example, do you have a DVD player or a Blu-ray player?). Write down the info for each device in the table below, under the remote key you want to use for that device.

	TV	STB	DVD
Device Example: Blu-ray player			
Brand Example: Sony			

### 3 Connect the remote to your computer.



Plug the USB cable's smaller connector into the port directly below the battery compartment on the back of the remote.

Plug the USB cable's larger connector into a USB port on your PC or Mac.

### 4 Set up your remote on SimpleSet.com

On your computer, open a web browser and go to [www.SimpleSet.com](http://www.SimpleSet.com)




Click on the Start Setup button at the bottom of the home page. Then follow the on-screen instructions to set up your remote.

### 5 Disconnect the remote from your computer.

When you're done using the online setup, follow the directions on SimpleSet.com to disconnect the remote from your computer. Then disconnect the USB cable from your remote.

### 6 Close the remote's battery door.



Press the door until it clicks into place.

### 7 Press and hold SETUP.



Press and hold the **SETUP** key until the **TV** key blinks twice.

**Note:** Make sure your device is on before you start. If you're programming a DVD player, media device, or anything else that plays back sound or video, make sure you have something playing.

### 8 Press the device key.




Press the key for the device you want to operate. For example, if you want to program the remote to operate your TV, press **TV**.

### 9 Point the remote at your device.



Keep the remote pointed directly at the front panel of the device you want to operate.


### 10 Press and hold the power key.



Press and hold the **power** key until your device turns off. Then release the key.

**Note:** If the original remote for this device doesn't have a power key, the One For All remote will send a pause command instead.

### 11 Test the remote with your device.



**If you're satisfied with the way the remote operates it:** Follow the Online Setup steps to program the remote for all of your devices.

**If the remote isn't operating your device like you think it should:** Try one of the other programming methods, described in the owners manual available at SimpleSet.com.

**To get the most from your One For All Remote,** make sure you set up One For All SmartControl. See the One For All SmartControl section on the other side of this guide for more information.

**Questions?** Just call 1-800-315-0990.