

RX-V450,550,650,750									
Function		Extended I/R				RX-V750	RX-V650	RX-V550	RX-V450
		Custom Code		Data Code					
MAIN POWER	ON	7	E	7	E	YES	YES	YES	YES
	OFF	7	E	7	F	YES	YES	YES	YES
ZONE2 POWER	ON	7	E	B	A	YES	YES	YES	NO
	OFF	7	E	B	B	YES	YES	YES	NO
ZONE2 MUTE	ON	7	E	A	0	YES	YES	YES	NO
	OFF	7	E	A	1	YES	YES	YES	NO
AUDIO MUTE	ON	7	E	A	2	YES	YES	YES	YES
	OFF	7	E	A	3	YES	YES	YES	YES
EXT INPUT	ON	7	E	A	4	YES	YES	YES	YES
	OFF	7	E	A	5	YES	YES	YES	YES
INPUT MODE	AUTO	7	E	A	6	YES	YES	YES	YES
	DTS	7	E	A	8	YES	YES	YES	YES
	ANALOG	7	E	A	A	YES	YES	YES	YES
SP RELAY A	ON	7	E	A	B	YES	YES	YES	YES
	OFF	7	E	A	C	YES	YES	YES	YES
SP RELAY B	ON	7	E	A	D	YES	YES	YES	YES
	OFF	7	E	A	E	YES	YES	YES	YES
OSD	OFF	7	E	B	0	YES	YES	NO	NO
	SHORT	7	E	B	1	YES	YES	NO	NO
	FULL	7	E	B	2	YES	YES	NO	NO
SLEEP	OFF	7	E	B	3	YES	YES	YES	YES
	120	7	E	B	4	YES	YES	YES	YES
	90	7	E	B	5	YES	YES	YES	YES
	60	7	E	B	6	YES	YES	YES	YES
	30	7	E	B	7	YES	YES	YES	YES
EX/ES	AUTO	7	E	7	C	YES	YES	YES	YES
	ON	7	E	7	D	YES	YES	YES	YES
	OFF	7	E	B	9	YES	YES	YES	YES
DC1 TRG CONTROL	ZONE1	7	E	3	2	YES	YES	YES	NO
	ZONE2	7	E	3	3	YES	YES	YES	NO
	ALL OR	7	E	3	4	YES	YES	YES	NO
DC1 TRIGGER ZONE1	ON	7	E	7	3	YES	YES	YES	NO
	OFF	7	E	7	4	YES	YES	YES	NO
DC1 TRIGGER ZONE2	ON	7	E	7	1	YES	YES	YES	NO
	OFF	7	E	7	2	YES	YES	YES	NO
EFFECT(STRAIGHT)	OFF(STRAIGHT)	7	E	E	0	YES	YES	YES	YES
	ON	7	E	2	7	YES	YES	YES	YES
NIGHT MODE	ON	7	E	9	B	YES	YES	YES	YES
	OFF	7	E	9	C	YES	YES	YES	YES
PROGRAMS	CONCERT HALL	7	E	E	5	YES	YES	YES	YES
	JAZZ CLUB	7	E	E	C	YES	YES	YES	YES
	ROCK CONCERT	7	E	E	D	YES	YES	YES	YES
	DISCO	7	E	F	0	YES	YES	YES	YES
	GAME	7	E	F	2	YES	YES	YES	YES
	7CH STEREO	7	E	F	F	YES	YES	YES	YES
	MUSIC VIDEO	7	E	F	3	YES	YES	YES	YES
	MONO MOVIE	7	E	F	7	YES	YES	YES	YES
	VARIETY SPORTS	7	E	F	8	YES	YES	YES	YES
	SPECTACLE	7	E	F	9	YES	YES	YES	YES
	SCI-FI	7	E	F	A	YES	YES	YES	YES
	ADVENTURE	7	E	F	B	YES	YES	YES	YES
	GENERAL	7	E	F	C	YES	YES	YES	YES
	SUR STANDARD	7	E	F	D	YES	YES	YES	YES
	SUR ENHANCED	7	E	F	E	YES	YES	YES	YES
	PLII(x) MOVIE	7	E	6	7	YES	YES	YES	YES
	PLII(x) MUSIC	7	E	6	8	YES	YES	YES	YES
	PLII(x) GAME	7	E	6	9	YES	YES	YES	YES
	NEO:6 CINEMA	7	E	6	A	YES	YES	YES	YES
	2ch Stereo	7	E	C	0	YES	YES	YES	YES
	Direct Stereo	7	E	C	1	NO	NO	YES	YES
FM/AM	FM	7	E	B	C	YES	YES	YES	YES
	AM	7	E	B	D	YES	YES	YES	YES
	AUTO TUNING UP	7	E	B	E	YES	YES	YES	YES
	AUTO TUNING DOWN	7	E	B	F	YES	YES	YES	YES