

RX-V420/520

Function	Standard I/R			
	Custom Code		Data Code	
CD INPUT	7	A	1	5
TUNER INPUT	7	A	1	6
TAPE/MD/CDR INPUT	7	A	C	9
DVD/LD INPUT	7	A	C	1
TV INPUT	7	A	5	4
VCR INPUT	7	A	0	F
AUX INPUT	7	A	1	4
V-AUX INPUT	7	A	5	5
6-CH INPUT	7	A	8	7
SLEEP (TOGGLE)	7	A	5	7
POWER ON/OFF	7	A	1	F
TEST	7	A	8	5
EFFECT ON/OFF	7	A	5	6
VOLUME UP	7	A	1	A
VOLUME DOWN	7	A	1	B
MUTE	7	A	1	C
TUNER PAGE TOGGLE	7	A	1	2
TUNER PAGE UP	7	A	1	0
TUNER PAGE DOWN	7	A	1	1
SET MENU	7	A	9	C
TIME/LEVEL	7	A	8	6
PRG +	7	A	5	8
PRG -	7	A	5	9
+	7	A	5	2
-	7	A	5	3
DSP PROGRAMS				
HALL	7	A	8	8
JAZZ			8	9
ROCK	7	A	8	A
ENTERTAINMENT(TOGGLE)	7	A	8	B
TV SPORTS	7	A	8	C
MONO MOVIE	7	A	8	D
MOVIE THEATER 1(TOGGLE)	7	A	8	E
MOVIE THEATER 2(TOGGLE)	7	A	8	F
DOLBY DIGITAL/DTS(TOGGLE)	7	A	9	0