

KX-W421 Standard IR Codes

Function	Standard I/R				
	Custom Code		Data Code		
STOP/PAUSE	7	A	0	4	
DECK A/B	7	A	0	6	
TAPE <<	7	A	0	1	
TAPE > PLAY	7	A	0	0	
TAPE >>	7	A	0	2	
DIR A	7	A	0	7	
TAPE STOP	7	A	0	3	
DIR B	7	A	4	0	