

RX-V4600					
FUNCTION		Extended I/R (NEC format)			
		ID1 setting(default)		ID2 setting	
		Custom Code	Data Code	Custom Code	Data Code
SYSTEM					
Main Power	ON	7E	7E	7D	B2
	OFF	7E	7F	7D	B1
Zone2 Power	ON	7E	BA	<--- same as ID1	
	OFF	7E	BB	<--- same as ID1	
Zone3 Power	ON	7A	ED	<--- same as ID1	
	OFF	7A	EE	<--- same as ID1	
Main Zone Mute	ON	7E	A2	<--- same as ID1	
	OFF	7E	A3	<--- same as ID1	
Zone2 Mute	ON	7E	A0	<--- same as ID1	
	OFF	7E	A1	<--- same as ID1	
Zone3 Mute	ON	7E	26	<--- same as ID1	
	OFF	7E	66	<--- same as ID1	
MULTI CH INPUT	ON	7E	A4	<--- same as ID1	
NORMAL INPUT	ON(= EXT INPUT: OFF)	7E	A5	<--- same as ID1	
INPUT MODE	AUTO	7E	A6	<--- same as ID1	
	D.D.RF	7E	A7	<--- same as ID1	
	DTS	7E	A8	<--- same as ID1	
	DIGITAL	7E	A9	<--- same as ID1	
	ANALOG	7E	AA	<--- same as ID1	
SP RELAY A	ON	7E	AB	<--- same as ID1	
	OFF	7E	AC	<--- same as ID1	
SP RELAY B	ON	7E	AD	<--- same as ID1	
	OFF	7E	AE	<--- same as ID1	
ON SCREEN	OFF	7E	B0	<--- same as ID1	
	SHORT	7E	B1	<--- same as ID1	
SLEEP	OFF	7E	B3	<--- same as ID1	
	120	7E	B4	<--- same as ID1	
	90	7E	B5	<--- same as ID1	
	60	7E	B6	<--- same as ID1	
	30	7E	B7	<--- same as ID1	
EX(6.1)/ES	AUTO	7E	7C	<--- same as ID1	
	ON	7E	7D	<--- same as ID1	
	EX/ES ON	7E	B8	<--- same as ID1	
	DOLBY EX	7E	DC	<--- same as ID1	
	PLIIX MOVIE	7E	DD	<--- same as ID1	
	PLIIX MUSIC	7E	DE	<--- same as ID1	
	OFF	7E	B9	<--- same as ID1	
DC1 TRG CTRL	ZONE1	7E	32	<--- same as ID1	
	ZONE2	7E	33	<--- same as ID1	
	ZONE3	7E	31	<--- same as ID1	
	ALL OR	7E	34	<--- same as ID1	
DC2 TRG CTRL	ZONE1	7E	96	<--- same as ID1	
	ZONE2	7E	97	<--- same as ID1	
	ZONE3	7E	9F	<--- same as ID1	
	ALL OR	7E	98	<--- same as ID1	
DC1 TRIGGER ZONE1	ON	7E	73	<--- same as ID1	
	OFF	7E	74	<--- same as ID1	
DC1 TRIGGER ZONE2	ON	7E	71	<--- same as ID1	
	OFF	7E	72	<--- same as ID1	
DC1 TRIGGER ZONE3	ON	7E	83	<--- same as ID1	
	OFF	7E	84	<--- same as ID1	
DC2 TRIGGER ZONE1	ON	7E	3E	<--- same as ID1	
	OFF	7E	3F	<--- same as ID1	
DC2 TRIGGER ZONE2	ON	7E	3C	<--- same as ID1	
	OFF	7E	3D	<--- same as ID1	
DC2 TRIGGER ZONE3	ON	7E	85	<--- same as ID1	
	OFF	7E	86	<--- same as ID1	

DSP				
PROGRAM	EFFECT ON	7E	27	<<-- same as ID1
	STRAIGHT(EFFECT OFF)	7E	E0	<<-- same as ID1
	2ch Stereo	7E	C0	<<-- same as ID1
	7ch Stereo	7E	FF	<<-- same as ID1
	Pure Direct ON	7E	80	<<-- same as ID1
	Pure Direct OFF	7E	82	<<-- same as ID1
	Hall in Munch	7E	E1	<<-- same as ID1
	Hall in Vienna	7E	E5	<<-- same as ID1
	Freiburg	7E	E8	<<-- same as ID1
	The Bottom Line	7E	EC	<<-- same as ID1
	The Roxy Theater	7E	ED	<<-- same as ID1
	Disco	7E	F0	<<-- same as ID1
	Game	7E	F2	<<-- same as ID1
	Pop/Rock	7E	F3	<<-- same as ID1
	Classical/Opera	7E	F5	<<-- same as ID1
	Mono Movie	7E	F7	<<-- same as ID1
	TV Sports	7E	F8	<<-- same as ID1
	Spectacle	7E	F9	<<-- same as ID1
	Sci-Fi	7E	FA	<<-- same as ID1
	Adventure	7E	FB	<<-- same as ID1
	General	7E	FC	<<-- same as ID1
	Normal	7E	FD	<<-- same as ID1
	Enhanced	7E	FE	<<-- same as ID1
	THX CINEMA	7E	C2	<<-- same as ID1
NIGHT MODE	CINEMA	7E	9B	<<-- same as ID1
	MUSIC	7E	CF	<<-- same as ID1
	OFF	7E	9C	<<-- same as ID1
SYSTEM MEMORY				
SAVE	1	7E	2B	<<-- same as ID1
	2	7E	2C	<<-- same as ID1
	3	7E	2D	<<-- same as ID1
	4	7E	2E	<<-- same as ID1
	5	7E	2F	<<-- same as ID1
	6	7E	30	<<-- same as ID1
LOAD	1	7E	35	<<-- same as ID1
	2	7E	36	<<-- same as ID1
	3	7E	37	<<-- same as ID1
	4	7E	38	<<-- same as ID1
	5	7E	39	<<-- same as ID1
	6	7E	3A	<<-- same as ID1
VOLUME MEMORY				
SAVE	1	7E	6B	<<-- same as ID1
	2	7E	6C	<<-- same as ID1
	3	7E	6D	<<-- same as ID1
	4	7E	6E	<<-- same as ID1
	5	7E	6F	<<-- same as ID1
	6	7E	70	<<-- same as ID1
LOAD	1	7E	75	<<-- same as ID1
	2	7E	76	<<-- same as ID1
	3	7E	77	<<-- same as ID1
	4	7E	78	<<-- same as ID1
	5	7E	79	<<-- same as ID1
	6	7E	7A	<<-- same as ID1

ZONE2 VOLUME MEMORY				
SAVE	1	7E	87	<<-- same as ID1
	2	7E	88	<<-- same as ID1
	3	7E	89	<<-- same as ID1
	4	7E	8A	<<-- same as ID1
	5	7E	8B	<<-- same as ID1
	6	7E	8C	<<-- same as ID1
LOAD	1	7E	8D	<<-- same as ID1
	2	7E	8E	<<-- same as ID1
	3	7E	8F	<<-- same as ID1
	4	7E	90	<<-- same as ID1
	5	7E	91	<<-- same as ID1
	6	7E	92	<<-- same as ID1
ZONE3 VOLUME MEMORY				
SAVE	1	7E	20	<<-- same as ID1
	2	7E	21	<<-- same as ID1
	3	7E	22	<<-- same as ID1
	4	7E	23	<<-- same as ID1
	5	7E	24	<<-- same as ID1
	6	7E	25	<<-- same as ID1
LOAD	1	7E	60	<<-- same as ID1
	2	7E	61	<<-- same as ID1
	3	7E	62	<<-- same as ID1
	4	7E	63	<<-- same as ID1
	5	7E	64	<<-- same as ID1
	6	7E	65	<<-- same as ID1
TUNER				
FM/AM	FM	7E	BC	<<-- same as ID1
	AM	7E	BD	<<-- same as ID1
	AUTO TUNING UP	7E	BE	<<-- same as ID1
	AUTO TUNING DOWN	7E	BF	<<-- same as ID1