

Extended IR code for RX-V757, 657, 557, 457						
FUNCTION		Code	RX-V757	RX-V657	RX-V557	RX-V457
MAIN POWER	ON	7E - 7E	YES	YES	YES	NO
	OFF	7E - 7F	YES	YES	YES	NO
ZONE2 POWER	ON	7E - BA	YES	YES	YES	NO
	OFF	7E - BB	YES	YES	YES	NO
ZONE2 MUTE	ON	7E - A0	YES	YES	YES	NO
	OFF	7E - A1	YES	YES	YES	NO
AUDIO MUTE	ON	7E - A2	YES	YES	YES	YES
	OFF	7E - A3	YES	YES	YES	YES
	SET LEVEL -20dB	7E - DF	YES	YES	YES	YES
MultiCH Input	ON	7E - A4	YES	YES	YES	YES
	OFF	7E - A5	YES	YES	YES	YES
INPUT MODE	AUTO	7E - A6	YES	YES	YES	YES
	DTS	7E - A8	YES	YES	YES	YES
	ANALOG	7E - AA	YES	YES	YES	YES
SP RELAY A	ON	7E - AB	YES	YES	YES	YES
	OFF	7E - AC	YES	YES	YES	YES
SP RELAY B	ON	7E - AD	YES	YES	YES	YES
	OFF	7E - AE	YES	YES	YES	YES
SP B SET	MAIN	7E - 28	YES	YES	YES	YES
	ZONE B	7E - 29	YES	YES	YES	YES
ZONE2 SP OUT	ON (Internal)	7E - 99	YES	YES	NO	NO
	OFF (External)	7E - 9A	YES	YES	NO	NO
DC1 TRG CTRL	ZONE1	7E - 32	YES	YES	YES	NO
	ZONE2	7E - 33	YES	YES	YES	NO
	ALL OR	7E - 34	YES	YES	YES	NO
DC1 TRG ZONE2	ON	7E - 71	YES	YES	YES	NO
	OFF	7E - 72	YES	YES	YES	NO
DC1 TRG ZONE1	ON	7E - 73	YES	YES	YES	NO
	OFF	7E - 74	YES	YES	YES	NO
ONSCREEN	OFF	7E - B0	YES	YES	NO	NO
	SHORT	7E - B1	YES	YES	NO	NO
	FULL	7E - B2	YES	YES	NO	NO
SLEEP	OFF	7E - B3	YES	YES	YES	YES
	120	7E - B4	YES	YES	YES	YES
	90	7E - B5	YES	YES	YES	YES
	60	7E - B6	YES	YES	YES	YES
	30	7E - B7	YES	YES	YES	YES
PURE DIRECT	ON	7E - 80	YES	YES	NO	NO
	OFF	7E - 82	YES	YES	NO	NO
NIGHT MODE	ON	7E - 9B	YES	YES	YES	YES
	OFF	7E - 9C	YES	YES	YES	YES
EX(6.1)/ES	AUTO	7E - 7C	YES	YES	YES	YES
	EX ON	7E - DC	YES	YES	YES	YES
	PLIIX Movie	7E - DD	YES	YES	NO	NO
	PLIIX Music	7E - DE	YES	YES	YES	YES
	EX/ES MTRX ON	7E - B8	YES	YES	YES	YES
	OFF	7E - B9	YES	YES	YES	YES
PROGRAM	STRAIGHT	7E - E0	YES	YES	YES	YES
	Vienna	7E - E5	YES	YES	YES	YES
	The Bottom Line	7E - EC	YES	YES	YES	YES
	The Roxt Theatre	7E - ED	YES	YES	YES	YES
	Disco	7E - F0	YES	YES	YES	YES
	Game	7E - F2	YES	YES	YES	YES
	Pop/Rock	7E - F3	YES	YES	YES	YES
	Mono Movie	7E - F7	YES	YES	YES	YES
	TV Sports	7E - F8	YES	YES	YES	YES
	Spectacle	7E - F9	YES	YES	YES	YES
	Sci-Fi	7E - FA	YES	YES	YES	YES
	Adventure	7E - FB	YES	YES	YES	YES
	General	7E - FC	YES	YES	YES	YES
	Standard	7E - FD	YES	YES	YES	YES
	Enhanced	7E - FE	YES	YES	YES	YES
	Xch Stereo	7E - FF	YES	YES	YES	YES
	2ch Stereo	7E - C0	YES	YES	YES	YES
	DIRECT STEREO	7E - C1	NO	NO	YES	YES
	EFFECT ON (STRAIGHT OFF)	7E - 27	YES	YES	YES	YES
FM/AM	FM	7E - BC	YES	YES	YES	YES
	AM	7E - BD	YES	YES	YES	YES
	AUTO TUNING UP	7E - BE	YES	YES	YES	YES
	AUTO TUNING DOWN	7E - BF	YES	YES	YES	YES