

| RX-V1200             |              |   |           |   |
|----------------------|--------------|---|-----------|---|
| Function             | EXTENDED I/R |   |           |   |
|                      | Custom Code  |   | Data Code |   |
| <b>SYSTEM</b>        |              |   |           |   |
| MAIN ZONE POWER ON   | 7            | E | 7         | E |
| MAIN ZONE POWER OFF  | 7            | E | 7         | F |
| ZONE 2 POWER ON      | 7            | E | B         | A |
| ZONE 2 POWER OFF     | 7            | E | B         | B |
| ZONE 2 MUTE ON       | 7            | E | A         | 0 |
| ZONE 2 MUTE OFF      | 7            | E | A         | 1 |
| AUDIO MUTE ON        | 7            | E | A         | 2 |
| AUDIO MUTE OFF       | 7            | E | A         | 3 |
| 6 CH INPUT ON        | 7            | E | A         | 4 |
| 6 CH INPUT OFF       | 7            | E | A         | 5 |
| INPUT MODE AUTO      | 7            | E | A         | 6 |
| INPUT MODE D.D.RF    | 7            | E | A         | 7 |
| INPUT MODE DTS       | 7            | E | A         | 8 |
| INPUT MODE DIGITAL   | 7            | E | A         | 9 |
| INPUT MODE ANALOG    | 7            | E | A         | A |
| SP RELAY A ON        | 7            | E | A         | B |
| SP RELAY A OFF       | 7            | E | A         | C |
| SP RELAY B ON        | 7            | E | A         | D |
| SP RELAY B OFF       | 7            | E | A         | E |
| OSD OFF              | 7            | E | B         | 0 |
| OSD SHORT            | 7            | E | B         | 1 |
| OSD FULL             | 7            | E | B         | 2 |
| SLEEP OFF            | 7            | E | B         | 3 |
| SLEEP 120            | 7            | E | B         | 4 |
| SLEEP 90             | 7            | E | B         | 5 |
| SLEEP 60             | 7            | E | B         | 6 |
| SLEEP 30             | 7            | E | B         | 7 |
| 6.1 / ES MATRIX ON   | 7            | E | B         | 8 |
| 6.1 / ES AUTO        | 7            | E | 7         | C |
| 6.1 / ES DESCRETE ON | 7            | E | 7         | D |
| 6.1 / ES OFF         | 7            | E | B         | 9 |
| DC TRIGGER ON        | 7            | E | 7         | 3 |
| DC TRIGGER OFF       | 7            | E | 7         | 4 |
| <b>DSP PROGRAM</b>   |              |   |           |   |
| EFFECT OFF           | 7            | E | E         | 0 |
| EFFECT ON            | 7            | E | 2         | 7 |
| HALL                 | 7            | E | E         | 6 |
| CHURCH               | 7            | E | E         | 8 |
| JAZZ CLUB            | 7            | E | E         | C |
| ROCK CONCERT         | 7            | E | E         | D |
| DISCO                | 7            | E | F         | 0 |
| GAME                 | 7            | E | F         | 2 |
| 6CH STEREO           | 7            | E | F         | F |
| MONO MOVIE           | 7            | E | F         | 7 |
| TV SPORTS            | 7            | E | F         | 8 |
| SPECTACLE            | 7            | E | F         | 9 |
| SCI-FI               | 7            | E | F         | A |
| ADVENTURE            | 7            | E | F         | B |
| GENERAL              | 7            | E | F         | C |

|                    |   |   |   |   |
|--------------------|---|---|---|---|
| NORMAL             | 7 | E | F | D |
| ENHANCED           | 7 | E | F | E |
| PLII MOVIE         | 7 | E | 6 | 7 |
| PLII MUSIC         | 7 | E | 6 | 8 |
| NEO:6 MOVIE        | 7 | E | 6 | 9 |
| NEO:6 MUSIC        | 7 | E | 6 | A |
| <b>HOME BANK</b>   |   |   |   |   |
| HOME BANK MAIN     | 7 | E | 2 | 0 |
| HOME BANK A        | 7 | E | 2 | 1 |
| HOME BANK B        | 7 | E | 2 | 2 |
| HOME BANK C        | 7 | E | 2 | 3 |
| PRESET MEMORY A    | 7 | E | 2 | B |
| PRESET MEMORY B    | 7 | E | 2 | C |
| PRESET MEMORY C    | 7 | E | 2 | D |
| PRESET RECALL A    | 7 | E | 3 | 5 |
| PRESET RECALL B    | 7 | E | 3 | 6 |
| PRESET RECALL C    | 7 | E | 3 | 7 |
| <b>VOLUME BANK</b> |   |   |   |   |
| VOLUME BANK MAIN   | 7 | E | 6 | 0 |
| VOLUME BANK A      | 7 | E | 6 | 1 |
| VOLUME BANK B      | 7 | E | 6 | 2 |
| VOLUME BANK C      | 7 | E | 6 | 3 |
| PRESET MEMORY A    | 7 | E | 6 | B |
| PRESET MEMORY B    | 7 | E | 6 | C |
| PRESET MEMORY C    | 7 | E | 6 | D |
| PRESET RECALL A    | 7 | E | 7 | 5 |
| PRESET RECALL B    | 7 | E | 7 | 6 |
| PRESET RECALL C    | 7 | E | 7 | 7 |
| <b>TUNER</b>       |   |   |   |   |
| FM                 | 7 | E | B | C |
| AM                 | 7 | E | B | D |
| AUTO TUNING UP     | 7 | E | B | E |
| AUTO TUNING DOWN   | 7 | E | B | F |