

RX-V430/530

Function	Standard I/R			
	Custom Code		Data Code	
CD INPUT	7	A	1	5
TUNER INPUT	7	A	1	6
MD/CDR INPUT	7	A	C	9
DVD INPUT	7	A	C	1
D-TV/CBL INPUT	7	A	5	4
VCR INPUT	7	A	0	F
V-AUX INPUT	7	A	5	5
6-CH INPUT	7	A	8	7
SLEEP (TOGGLE)	7	A	5	7
SYSTEM POWER	7	A	1	D
STANDBY	7	A	1	E
VOLUME UP	7	A	1	A
VOLUME DOWN	7	A	1	B
MUTE	7	A	1	C
TEST	7	A	8	5
TUNER PRESET UP	7	A	1	0
TUNER PRESET DOWN	7	A	1	1
TUNER PAGE TOGGLE	7	A	1	2
LEVEL	7	A	8	6
SETMENU	7	A	9	C
+	7	A	5	2
-	7	A	5	3
UP	7	A	9	8
DOWN	7	A	9	9
DSP PROGRAMS				
EFFECT/STEREO	7	A	5	6
HALL	7	A	8	8
JAZZ CLOB	7	A	8	9
ROCK CONCERT	7	A	8	A
ENTERTAINMENT(TOGGLE)	7	A	8	B
TV SPORTS	7	A	8	C
MONO MOVIE	7	A	8	D
MOVIE THEATER 1(TOGGLE)	7	A	8	E
MOVIE THEATER 2(TOGGLE)	7	A	8	F
DOLBY DIGITAL/DTS(TOGGLE)	7	A	9	0
MATRIX 6.1	7	A	9	7
SELECT	7	A	9	6