

YSP-900/1100 IR code table					IR CODE 78 7E	232C	
	toggle contents			bottom state			
<b>system</b>	Power	ON/Standby		Toggle	78 CC	NG	
	Audio Mute	ON/OFF		Toggle	78 9C	OK	
	Input [TV/STB]			select	78 DF	OK	
	Input [VCR]			select	78 49	OK	
	Input [DVD]			select	78 4A	OK	
	Input [AUX]			select	78 DE	OK	
	Input mode	analog/DTS/AAC(4)		Toggle	78 8D	NG	
	Master volume [UP]			select	78 1E	OK	
	[DOWN]			select	78 1F	OK	
	Sleep timer	120/90/60/30/OFF min		Toggle	78 4F	OK	
<b>Sound field</b>	SURROUND	Dolby Pro/neo6		Toggle	78 99	NG	
	Cinema DSP [MOVIE]	Sci-Fi/Spectacle/Adv		Toggle	78 D9	NG	
	Cinema DSP [MUSIC]	Music video/Hall/Jazz		Toggle	78 DA	NG	
	Cinema DSP [SPORTS]			select	78 DB	NG	
	Cinema DSP : OFF			select	78 9B	OK	
	Volume mode	Night Listening/TV EQ Vol/OFF		Toggle	78 8A	NG	
	SRS TruBass	MID/DEEP/OFF		Toggle	78 8B	NG	MID:YSP-1100 only
	Level	ON/OFF		Toggle	78 48	NG	
	Test (Dolby)	ON/OFF		Toggle	78 5F	NG	
	Beam mode [5 Beam]			select	78 C2	OK	
	Beam mode [ST+3 Beam]			select	78 C3	OK	
	Beam mode [3 Beam]			select	78 C4	OK	
	Beam mode [Stereo]			select	78 50	OK	
	Beam mode [My Beam]	(Just changed to My Beam. Some)		select	78 C5	OK	
<b>Others</b>	Set Menu			enter to state	78 9D	NG	
	IntelliBeam Start Trigger			select	78 A3		
	entry [Up]			select	78 8E	NG	
	entry [Down]			select	78 8F	NG	
	entry [Right]			select	78 9E	NG	
	entry [Left]			select	78 9F	NG	
	ENTER			select	78 C1	NG	
	RETURN			select	78 C0	NG	
	Dual Mono	MAIN/SUB/MAIN+SUB		Toggle	78 A5	NG	J Dest Only

YSP-900/1100 Extended IR function					IR CODE 78 7E	232C	
<b>system</b>	main power	ON			78 7E		
		OFF			78 7F		
	Audio mute	ON Mute			7E A2		
		ON -20dB			7E DF		
		OFF			7E A3		
	Input mode	AUTO			7E A6		
		DTS			7E A8		
		ANALOG			7E AA		
		AAC			7E 3B		J Dest Only
	Sleep	OFF			7E B3		
<b>Sound Field</b>		120			7E B4		
		90			7E B5		
		60			7E B6		
		30			7E B7		
	NIGHT MODE	CINEMA			7E 9B		
		MUSIC			7E CF		
	NIGHT MODE, TV MODE	OFF			7E 9C		
	TV MODE	ON			78 7C		
	TruBass	ON (DEEP/1100)			78 6E		
		ON (MID/1100 only)			78 6D		
<b>Sound Field</b>		OFF			78 6F		
	Surround	PRO LOGIC			7E FD		
		PLII MOVIE			7E 67		
		PLII MUSIC			7E 68		
		PLII GAME			7E C7		
		NEO:6 MOVIE			7E 69		
		NEO:6 MUSIC			7E 6A		
	CINEMA DSP	Spectacle (YSP-1100)	MOVIE		7E F9		
		Sci-Fi (SFX) (YSP-900,1100)	MOVIE		7E FA		
		Adventure (YSP-1100)	MOVIE		7E FB		
<b>Sound Field</b>		Concert Hall (YSP-1100)	MUSIC		7E E1		
		Jazz Club (YSP-1100)	MUSIC		7E EC		
		Music Video (YSP-900,1100)	MUSIC		7E F3		
		SPORTS (YSP-900,1100)	SPORTS		7E F8		
<b>Volume mem</b>	Preset memory	A			78 70		
		B			78 72		
		C			78 74		
	Preset Call	A			78 71		
		B			78 73		
		C			78 75		
<b>BEAM MEMORY</b>	MEMORY SAVE	USER1			78 76		
		USER2			78 78		
		USER3			78 7A		
	MEMORY LOAD	USER1			78 77		
		USER2			78 79		
		USER3			78 7B		
<b>Others</b>	DUAL MONO	MAIN			7E 93	—	J Dest Only
		SUB			7E 94	—	J Dest Only
		MAIN+SUB			7E 95	—	J Dest Only
	DEMO MODE	DEMO-1 ON (Outside sound source)			78 6B		*Effective in DEMO MODE ON
		DEMO-1 OFF			78 6C		
		DEMO-2 ON (Inside sound source)			78 69		
		DEMO-2 OFF			78 6A		