

Standard IR code for RX-797, 497, 397 (NEC code)					
FUNCTION	ID1 CODE*	ID2 CODE* (Default)	RX-797	RX-497	RX-397 (only ID2)
<b>ALL ZONE</b>					
POWER ON	7A-1D	7D-90	YES	YES	YES
STANDBY	7A-1E	7D-91	YES	YES	YES
<b>MAIN</b>					
POWER ON	7E-7E	7D-B2	YES	YES	YES
STANDBY	7E-7F	7D-B1	YES	YES	YES
CD	7A-15	7D-87	YES	YES	NO
CD/DVD	-	7D-87	NO	NO	YES
MD/TAPE	7A-18	7D-8B	YES	YES	NO
MD	-	7D-86	NO	NO	YES
TAPE	-	7D-8B	NO	NO	YES
TUNER	7A-16	7D-89	YES	YES	YES
XM	7A-B4	7D-29	YES	YES	NO
DVD	7A-C1	7D-97	YES	YES	NO
DTV/CBL	7A-54	7D-84	YES	YES	NO
VCR	7A-0F	7D-81	YES	YES	NO
PHONO	7A-14	7D-88	YES	YES	YES
AUX	-	7D-8A	NO	NO	YES
VOLUME(VOL) +	7A-1A	7D-8D	YES	YES	YES
VOLUME(VOL) -	7A-1B	7D-8E	YES	YES	YES
MUTE	7A-1C	7D-94	YES	YES	YES
SPEAKERS A	7A-9A	7D-E7	YES	YES	YES
SPEAKERS B	7A-9B	7D-E8	YES	YES	YES
SLEEP	7A-57	7D-93	YES	YES	YES
<b>ZONE2</b>					
POWER ON	7E-BA	7D-64	YES	YES	NO
STANDBY	7E-BB	7D-63	YES	YES	NO
CD	7A-D1	7D-67	YES	YES	NO
MD/TAPE	7A-D3	7D-6A	YES	YES	NO
TUNER	7A-D2	7D-66	YES	YES	NO
XM	7A-B8	7D-2F	YES	YES	NO
DVD	7A-CD	7D-6F	YES	YES	NO
DTV/CBL	7A-D9	7D-6C	YES	YES	NO
VCR	7A-D6	7D-6D	YES	YES	NO
PHONO	7A-D0	7D-65	YES	YES	NO
VOLUME(VOL) +	7A-DA	7D-70	YES	NO	NO
VOLUME(VOL) -	7A-DB	7D-71	YES	NO	NO
MUTE	7A-DC	7D-72	YES	YES	NO
<b>TUNER ( AM / FM )</b>					
PRESET/CH UP	7A-10	7D-F5	YES	YES	YES
PRESET/CH DOWN	7A-11	7D-F6	YES	YES	YES
A-E/CAT. +	7A-12	7D-F7	YES	YES	YES
A-E/CAT. -	7A-AC	7D-BB	YES	YES	YES
BAND	7A-AE	7D-BD	YES	YES	YES
MEMORY	7A-AF	7D-BE	YES	YES	YES
PRESET NUMBER / NUMERIC BUTTON	1	7A-E5	7D-F8	YES	YES
	2	7A-E6	7D-F9	YES	YES
	3	7A-E7	7D-FA	YES	YES
	4	7A-E8	7D-FB	YES	YES
	5	7A-E9	7D-FC	YES	YES
	6	7A-EA	7D-FD	YES	YES
	7	7A-EB	7D-FE	YES	YES
	8	7A-EC	7D-FF	YES	YES
<b>TUNER ( XM )</b>					
PRESET/CH UP	7A-6A	7D-31	YES	YES	NO
PRESET/CH DOWN	7A-6B	7D-32	YES	YES	NO
A-E/CAT. +	7A-6C	7D-33	YES	YES	NO
A-E/CAT. -	7A-6E	7D-35	YES	YES	NO
SRCH MODE	7A-6D	7D-34	YES	YES	NO
MEMORY	7A-71	7D-38	YES	YES	NO
DISPLAY	7A-72	7D-39	YES	YES	NO
PRESET NUMBER / NUMERIC BUTTON	1	7A-61	7D-A1	YES	NO
	2	7A-62	7D-A2	YES	NO
	3	7A-63	7D-A3	YES	NO
	4	7A-64	7D-A4	YES	NO
	5	7A-65	7D-A5	YES	NO
	6	7A-66	7D-A6	YES	NO
	7	7A-67	7D-A7	YES	NO
	8	7A-68	7D-A8	YES	NO
	9	7A-69	7D-A9	YES	NO
	0	7A-60	7D-A0	YES	NO
ENT.	7A-BF	7D-3F	YES	YES	NO

\* Please refer to owner's manual to change ID setting.